




HP ProBook 4320t Power Button Panel Replacement Guide

Replacing a bent or scratched power button panel.

Written By: Joshua



INTRODUCTION

The power button panel is one of the easiest components to replace on the HP 4320t. It may need replacing, if damaged, to insure proper working order.



TOOLS:

- [Phillips #0 Screwdriver](#) (1)
-

Step 1 — Battery Removal



- Flip the laptop upside down and remove battery by pressing inward on the two latches holding the battery in.

Step 2 — Screws



- Unscrew the four (2.5 mm Phillips) screws (Use Phillips #0 Screwdriver).

Step 3 — Flip



- Flip laptop over and open it.

Step 4 — Push N Lift



- Slightly push up while lifting up on the power button panel to release the panel.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-08-14 05:31:38 PM.